



Effortlessly create perfect snacks and dishes
WITH THE PERFECT SLICER
 Slice melons, vegetables, cakes and so much more!


⚠ WARNING: EXTREMELY SHARP BLADES!

USE CAUTION WHILE HANDLING. KEEP OUT OF REACH OF CHILDREN.




STEP 1

Cut off 1/2" to 1" from both ends of the melon.



STEP 2

Place the melon upright on a safe, flat surface. Firmly grip both handles. Insert the slicer into the melon.



STEP 3

Apply some pressure while pushing down. Gently rock the slicer back and forth continuing to push the slicer down through the entire fruit.



STEP 4

Remove the core of the fruit from the slicer. Then gently slide the Perfect Slicer up through the fruit.

Yields 12 perfect slices • Safe and easy to use • Blade protector allows for safe storage
 Perfectly slice cakes, fruits and veggies • Top Rack Dishwasher safe

THIS PRODUCT IS NOT INTENDED TO BE USED BY CHILDREN. ADULT SUPERVISION IS REQUIRED. ALTHOUGH BLADES HAVE A PROTECTIVE COVER, STORE IN A SAFE LOCATION AWAY FROM THE REACH OF CHILDREN.



Distributed by: Tristar Products, Inc.
 Fairfield, NJ 07004. ©2014 Tristar Products, Inc.

PS_CCM_IB_TP_ENG_V3_140814