

Quick Start Guide

*Please read all instructions for use before cooking with the Copper Chef Induction Cooktop.

Just 5 Easy Steps to Get You Started...

Step 1



First, simply plug your Copper Chef Induction Cooktop into a standard household outlet.

Step 2



Second, place an induction pan on your Induction Cooktop. You **MUST** use an **induction-ready*** pot or pan.


Step 3



Now, select one of the preset temperature buttons. There are 5 choices: **KEEP WARM, LOW, MED, HIGH, or SEAR.**

NOTE: You can also adjust the temperature manually with the UP and DOWN arrows.

Step 4



Next, press the **START/OFF** button. The Cooktop will begin heating and the interior fan will turn on. Now you may add your food.


NOTE: If you remove the pan from the cooking surface the Induction Cooktop will stop heating and begin to beep. Returning the pan to the Cooktop will resume heating.

Step 5




Finally, to end the cooking process, press the **START/OFF** button.

NOTE: After cooking, let the unit cool down by keeping it plugged in and without the temperature on. You will hear the interior fan stay on as it cools down.



Look for the induction symbol.



***Induction-ready** refers to cookware having an induction plate on the bottom as shown, or if no induction plate the cookware must be magnet-friendly. If a magnet sticks to the bottom, it will work with the Induction Cooktop.



CAUTION:
Hot Surface When Heated.
Read All Instructions and Safeguards Before Use.