



8QT Quick Start Guide*

* See owner's manual for complete instructions and important safety information before using this product.

Step 1



Place Inner Pot into the unit.

Step 2



Add ingredients.

Step 3



Place Lid on Cooker with Handle and Recessed Valve pointed to the "10:00 o'clock" position. Rotate Lid counter-clockwise until you feel a click.

Step 4



Rotate Pressure Valve to the lock position.

NOTE: The Power Cooker Plus will take 15 - 17 minutes to pressurize before it starts to cook.

Step 5



Follow your recipe for correct cook time.

Step 6




For easiest cleanup, wash Power Pressure Cooker parts immediately after cooking. Place dishwasher safe parts on the top rack only.

Wash All Components Before First Use












Digital Control Panel — Overview

The Power Cooker Plus has up to seven basic cooking modes that may be used alone or in combination to produce an infinite variety of results. This Quick Start Guide provides Step-By-Step instructions.



WHEN THE UNIT IS FIRST PLUGGED IN, 0000 will appear on the LED Display. When a cooking process is selected, such as COOK, the default time will blink 5 times. Then, rotating double zeros may appear on the left side of the screen to signify it is building pressure. Once pressure is built, the zeros will stop rotating and begin counting down the time. The unit will beep, and the LED Display will be blank. Enter KEEP WARM mode once the time has expired until cancelled.

NOTE: Go to page 6 of the manual for complete control information.

MODE	DESCRIPTION
1 	DELAY TIMER Button — Delays the cooking start time. It will change in 30-minute increments.
2 	CANNING / PRESERVING Button — Higher pressure setting used mainly for Canning & Preserves. It can be changed in 10-minute increments.
3 	SOUP / STEW Button — Medium Pressure. It can be changed in 1-minute increments.
4 	SLOW COOK Button — Low Pressure. It can be changed in 30-minute increments.
5 	RICE / RISOTTO Button — Medium Pressure. Pre-set time & pressure for white rice, brown rice, & wild rice. It can be changed in 1-minute increments.
6 	COOK TIME SELECTOR Button — Use to scroll through each button's pre-selected times – Quick, Medium, Well.
7 	BEANS / LENTILS Button — Medium Pressure. It can be changed in 1-minute increments.
8 	FISH / VEGETABLES STEAM Button — Medium Pressure. It can be changed in 1-minute increments.
9 	CHICKEN / MEAT Button — Medium Pressure. It can be changed in 1-minute increments.
10 	TIME ADJUSTMENT Button — Use to change default times on preset buttons. Scroll up only.
11 	KEEP WARM / CANCEL Button — While the unit is in a cooking cycle, pressing the button will stop the cooking cycle.