

Quick Start Guide

SHAQTM

Smokeless Grill & Press

See owner's manual for complete instructions and important safety information before using this product.

STEP 1



Assemble the packed parts and ensure that the Grill Plate and Drip Trays are in place (see reverse side for detailed instructions). Attach the Power Cord to the Appliance Base and then plug the Power Cord into an outlet.

STEP 2



Close the Lid. Set a cooking time and temperature. Allow the appliance to preheat. When the appliance has preheated, it will beep and the set cooking time will begin to count down.

STEP 3




Use the handle to open the Lid and place your food on the Bottom Grill Plate.

STEP 4



When your food is done cooking, use a plastic or wooden spatula to transfer the food to a plate or cutting board.

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm, soapy water before first use (only select accessories are dishwasher safe).



*Griddle Plate may be sold separately.

NOTE: The Top and Bottom Grill Plates are removable.
The Top Heating Element is fixed and cannot be removed.